



Slide the rollers bearings apart to make it curve away from the battery box.



Keep chains tight on this end, adjust the other end.

Slide the rollers bearings together to make it curve toward the battery box.



Keep chains tight on this end, adjust the other end.

BOBKART roller alignment

11/27/2018